

AREZZO

1

2

3

4

5

6

| | | |
|------------------|--|---|
| A | | 1 |
| B | | 1 |
| C+C ₁ | | 1 |
| D | | 1 |
| E | | 1 |
| F | | 5 |
| G | | 1 |
| H | | 1 |
| I | | 6 |
| J | | 6 |
| K | | 4 |
| L | | 4 |
| M | | 1 |
| M ₁ | | 1 |

max. 100 kg

v.2

HALMAR Sp. z o.o.
 ul. Centralnego Okręgu Przemysłowego 2, 37-450 Stalowa Wola, POLSKA / POLAND
 tel. +48 15 843 28 10, fax: +48 15 842 19 57, e-mail: office@halmar.com.pl