




















ASSEMBLY INSTRUCTION **model HARMONY C**

| | | | | | | |
|---|---|---|--|---|---|--|
| 1. -2 Pcs.  | 2. -2 Pcs.  | 3. -3 Pcs.  | 4. -1 Pc.  | 5. -2 Pcs.  | 6. -2 Pcs.  | 7. -1 Pc.  |
| 8. -2 Pcs.  | 9. -1 Pc.  | | | | | |

| | | | | | |
|--|---|---|--|--|--|
| A. -10 Pcs.  | B. -4 Pcs.  | C. -1 Pc.  | D. -10 Pcs.  | E. -10 Pcs.  | F. -12 Pcs.  |
| G. -4 Pcs.  | H. -4 Pcs.  | I. -8 Pcs.  | J. -2 Pcs.  | | |

